

# Silt Fence

1. Drive steel post a minimum of 24" into the ground and excavate a 6" x 6" trench up-hill along the line of the posts. Maximum of 8' between posts with Hog Wire Fence or 6' without using fence backing.
2. Attach wire fence to posts and extend the bottom of the fence 8" into the excavated trench.
3. Attach the filter fabric to the wire fence and extend the bottom of the fabric 8" into the trench.
4. Backfill trench and compact the #57 Stone or fill dirt firmly to anchor the bottom of the silt fence so that runoff is forced through the fence and cannot go under it.

